


SYNCRA



Spare parts. *Subject to change without prior notice.


SYNCRA HF



SYNCRA 0.5 SYNCRA 1.0

Syncra 0.5
SGR0049 (230V)
SGR0050 (120V)


Syncra 1.0
SGR0051 (230V)
SGR0052 (120V)



Accessory:
SGR0096 - Ceramic shaft+rubbers

SYNCRA 1.5

Syncra 1.5
SGR0053 (230V)
SGR0054 (120V)



Accessory:
SGR0098 - Ceramic shaft+rubbers

SYNCRA 2.0 SYNCRA 2.5 SYNCRA 3.0 SYNCRA 3.5 SYNCRA 4.0 SYNCRA 5.0

Syncra 2.0
SGR0047 (230V)
SGR0058 (120V)

Syncra 2.5
SGR0057 (230V)


Syncra 3.0
SGR0048 (230V)
SGR0059 (120V)

Syncra 3.5
SGR0069 (230V)
SGR0070 (120V)

Syncra 4.0
SGR0069 (230V)
SGR0070 (120V)

Syncra 5.0
SGR0069 (230V)
SGR0070 (120V)

Syncra 3.5-4.0-5.0
SGR0122 - Ceramic shaft+rubbers



SYNCRA HF 10 SYNCRA HF 12 SYNCRA HF 16

Syncra 12.0-16.0
STR0016

Syncra 10.0
STR0002

