

VOYAGER 1
 VOYAGER 2
 VOYAGER 3
 VOYAGER 4




VOYAGER 7
 VOYAGER 8
 VOYAGER 9
 VOYAGER 10



Spare parts. *Subject to change without prior notice.

VOYAGER 1




**VOYAGER 2
 VOYAGER 3
 VOYAGER 4**

Voyager 2:
 SGR0080 (230V)
 SGR0081 (120V)

Voyager 3:
 SGR0082 (230V)
 SGR0083 (120V)

Voyager 4:
 SGR0084 (230V)
 SGR0080 (120V)



**VOYAGER 7
 VOYAGER 8
 VOYAGER 9
 VOYAGER 10**

